



GUIDE PORTAL: Vehicle Tips

Vehicle Tips – When getting in the driver seat

- Outside visual check:
 - Check tires (tread & air)
 - Check for dents/scratches
 - Check for Bikes/Cyclists around van
- Inside Visual check:
 - Check for any warning lights on dashboard
 - Please note that almost all the vans have a bad tire pressure sensor... It's expensive to fix and should be done when the van gets new tires (but it breaks often). If you are nervous about the tire PSI, please get out and visually check or measure the tire pressure.
- Adjust Seat & Steering wheel to your comfort level
- Adjust Mirrors
 - Driver's side and Passenger's side – Adjust so you can see your blind spots and the trailer if you are towing. This adjustment is different for everyone.
 - Rearview mirror (even if you are pulling a trailer)